

## PRODUCT DATA SHEET

# Sika® Wonder Wipes

## MULTI-USE CLEANING WIPES FOR THE BUILDING TRADE

## DESCRIPTION

Sika® Wonder Wipes are specially formulated to clean hands, tools and surfaces from wet and semi-cured paint, sealant, adhesive, bitumen, expanding foam, oil, grease and even silicone. Particularly useful when there is no water on site.

## USES

Cleaning wet and semi-cured paints, sealants, adhesives, bitumen, polyurethanes, expanding foams, polyester fillers and epoxies from hands, tools and surfaces.

## PRODUCT INFORMATION

<b>Packaging</b>	Tub containing 100 wipes
<b>Shelf Life</b>	Sika® Wonder Wipes must be used within 36 months from the date of manufacture and within 6 months from opening.
<b>Storage Conditions</b>	Store in cool dry conditions away from direct sunlight between +5 °C and +25 °C. Storage outside these parameters will significantly reduce shelf life.

## BASIS OF PRODUCT DATA

All technical data stated in this Product Data Sheet are based on laboratory tests. Actual measured data may vary due to circumstances beyond our control.

## USES

- Do not use on porous surfaces such as untreated wood.
- Do not dispose of wipes in toilets.
- Use only as directed.
- Store only in original container.
- As with all detergents / products containing detergents, people with sensitive or damaged skin should avoid prolonged contact with skin.

## CHARACTERISTICS / ADVANTAGES

- Cleans hands, tools and surfaces.
- Formulated to remove the toughest of grime.
- Contains an anti-bacterial additive.
- Contains aloe vera to condition skin and prevent dryness and cracking.

## APPROVALS / STANDARDS

Sika® Wonder Wipes contain an anti-bacterial additive tested by an independent laboratory to EN 1276 chemical disinfectants and antiseptics.

- It is the users responsibility to determine suitability for use. If in doubt, contact our Technical Services department for advice.

## ECOLOGY HEALTH AND SAFETY

For information and advice on the safe handling, storage and disposal of chemical products, users should refer to the most recent Safety Data Sheet.

## APPLICATION INSTRUCTIONS

### APPLICATION METHOD / TOOLS

#### Tub

To use Wonder Wipes pull off lid and open foil closure. Find the start wipe in the centre of the roll. Pull out

approx 30cms of wipes and thread through the plastic lid of the tub. Replace lid immediately and reseal closure. Wipes are now ready to be dispensed and used as required.

## LOCAL RESTRICTIONS

Please note that as a result of specific local regulations the performance of this product may vary from country to country. Please consult the local Product Data Sheet for the exact description of the application fields.

## LEGAL NOTES

The information, and, in particular, the recommendations relating to the application and end-use of Sika products, are given in good faith based on Sika's current knowledge and experience of the products when properly stored, handled and applied under normal conditions in accordance with Sika's recommendations. In practice, the differences in materials, substrates and actual site conditions are such that no warranty in respect of merchantability or of fitness for a particular purpose, nor any liability arising out of any legal relationship whatsoever, can be inferred either from this information, or from any written recommendations, or from any other advice offered. The user of the product must test the product's suitability for the intended application and purpose. Sika reserves the right to change the properties of its products. The proprietary rights of third parties must be observed. All orders are accepted subject to our current terms of sale and delivery. Users must always refer to the most recent issue of the local Product Data Sheet for the product concerned, copies of which will be supplied on request. It may be necessary to adapt the above disclaimer to specific local laws and regulations. Any changes to this disclaimer may only be implemented with permission of Sika® Corporate Legal in Baar.

**Sika (NZ) Limited**  
85-91 Patiki Road  
Avondale, Auckland 1026  
New Zealand  
0800 745 269  
www.sika.co.nz



**Product Data Sheet**  
**Sika® Wonder Wipes**  
January 2024, Version 01.01  
02051602000000082

SikaWonderWipes-en-NZ-(01-2024)-1-1.pdf

