

PRODUCT DATA SHEET

Sika Boom® Cleaner

PU foam cleaner for Sika Boom® application guns and foam residues

DESCRIPTION

Sika Boom® Cleaner is suitable for cleaning Sika Boom® application guns and fresh PU foam residues from tools and surfaces.

USES

- Flushing the inside of the Sika Boom® application guns after use
- Removing fresh, uncured PU foam residues from tools and other surfaces
- Cleaning and removing grease from contaminated substrates

CHARACTERISTICS / ADVANTAGES

- Dissolves uncured PU foam effectively
- Easy and quick flushing of the application gun
- Attached nozzle for precise manual application

PRODUCT INFORMATION

Chemical Base	Solvent-based cleaning agent	
Packaging	500 ml pressurised canister with rubber valve	12 canisters per box
Colour	Transparent	
Shelf Life	24 months	
Storage Conditions	The Product must be stored in original, unopened and undamaged sealed packaging in dry conditions at temperatures between +5 °C and +25 °C. Store in an upright position. Protect the canister from direct sunlight and temperatures above +50 °C (danger of exploding). Always refer to packaging.	
Density	~0,70 kg/l	

APPLICATION INFORMATION

Product Temperature	Minimum	+5 °C
	Maximum	+30 °C

BASIS OF PRODUCT DATA

All technical data stated in this Product Data Sheet are based on laboratory tests. Actual measured data may vary due to circumstances beyond our control.

ECOLOGY HEALTH AND SAFETY

For information and advice on the safe handling, storage and disposal of chemical products, users shall refer to the most recent Safety Data Sheet (SDS) containing physical, ecological, toxicological and other safety-related data.

APPLICATION INSTRUCTIONS

APPLICATION METHOD / TOOLS

IMPORTANT

Clean immediately

Clean all tools and substrates immediately after the application. Cured material can only be removed mechanically.

IMPORTANT

Potential discolouration

The Product can partly dissolve or discolour sensitive substrates (e.g. varnish, paint, plastics, textiles). We recommend testing the compatibility and colour fastness discretely on an unobtrusive small area before use.

IMPORTANT

Canister orientation

To ensure proper flow, hold the canister upside down while dispensing.

IMPORTANT

Do not open the product using excessive force.

IMPORTANT

The cleaner discharges with high pressure.

CLEANING BY NOZZLE

The Product with the attached nozzle can be used to clean the outside of the application gun or to remove residues from tools and substrates.

1. Mount the attached nozzle on top of the valve of the Product.
2. Spray the Product directly onto the fresh foam by pressing the nozzle and allow it to react for 5–10 seconds.
3. Wipe-off the residue with a clean cloth.

FLUSHING THE APPLICATION GUN

The Product without the attached nozzle can be used to flush the application gun.

1. Screw the canister onto the application gun immediately after removing the foam canister.
2. Press the trigger of the application gun a few times to flush out all uncured foam residue.
3. Wait 2 minutes and repeat pressing the trigger until clean liquid comes out of the application gun.
4. After cleaning, remove the canister from the application gun and release all remaining Product inside the application gun

LOCAL RESTRICTIONS

Please note that as a result of specific local regulations the performance of this product may vary from country to country. Please consult the local Product Data Sheet for the exact description of the application fields.

LEGAL NOTES

The information, and, in particular, the recommendations relating to the application and end-use of Sika products, are given in good faith based on Sika's current knowledge and experience of the products when properly stored, handled and applied under normal conditions in accordance with Sika's recommendations. In practice, the differences in materials, substrates and actual site conditions are such that no warranty in respect of merchantability or of fitness for a particular purpose, nor any liability arising out of any legal relationship whatsoever, can be inferred either from this information, or from any written recommendations, or from any other advice offered. The user of the product must test the product's suitability for the intended application and purpose. Sika reserves the right to change the properties of its products. The proprietary rights of third parties must be observed. All orders are accepted subject to our current terms of sale and delivery. Users must always refer to the most recent issue of the local Product Data Sheet for the product concerned, copies of which will be supplied on request. It may be necessary to adapt the above disclaimer to specific local laws and regulations. Any changes to this disclaimer may only be implemented with permission of Sika® Corporate Legal in Baar.

Sika (NZ) Limited

85-91 Patiki Road
Avondale, Auckland 1026
New Zealand
0800 745 269
www.sika.co.nz



Product Data Sheet

Sika Boom® Cleaner

November 2024, Version 03.01
02051602000000015

SikaBoomCleaner-en-NZ-(11-2024)-3-1.pdf

